

Hopper model list

450 835-3434

info@ychamberland.com

Size	Model 10 GA	Model 3/16	Model 3/16 with lifting logs	A	B	C	D	E
½ YARD	BMV	BMV-188		43	31	42	12	28,5
¾ YARD	B75V	B75V-188		57	37	42	12	28,5
1 YARD	B1V	B1V-188	YC-1001	61	42	42	12	28,5
1 ½ YARDS	B15V	B15V-188		61	42	58	25	42
2 YARDS	B2V	B2V-188	B2V-188S	68	46	58	25	42
3 YARDS	B3V	B3V-188		75	53	59	25	42
4 YARDS	B4V	B4V-188		75	53	65	25	42
5 YARDS	B5V	B5V-188		75	53	77	25	42



Spare parts

Handle

Spring

Option

Casters 6 in (2 fixed and 2 swiveling)

Non-standard paint

